

Table of Contents

YCE

Client

Site

Nodes / Services

Create a new node

Graph

Connections overview

3

3

4

4

4

6

7

YCE

When the build phase is chosen, the main build form is shown. This page is divided 3 areas: the clients, sites and nodes/services area.

netYCE

<

Search

Inventory

YCE

CMDB

Node groups

Design

Build

Operate

Compliance

Backups

Reports

Admin

DOCS

Wiki

Service types | Compliance | YCE | CMDB | Node types

nyeve

Eric Yspeert

Logout

LAB

Client code	Client type	Client name	Region	Supernets	Client statu...	Permissions
BT93812	ZDE	KDE	Region	0	active	Manager
campus	campus	YCE-campus	campus	2	active	Manager
LAB	YCE	14 node lab	YCE	0	active	Manager
ServerComp...	DCvxlan	ServerCompany	DCvxlan	0	active	Manager
sp	sp		sp	0	active	Manager

New

Edit

Delete

Graph

Search

Search:

Sites

VPN

Site code	Site type	Address	Zip	City	Status	Mig.
EVE-ng	LAB				active	0

New

Edit

Delete

Graph

Search

Nodes

Services

Nodename	Node_class	Pos	Template	Status	Evpn via...	IPv6 Address
campus1	LAB	SV	campus001	planned		
HP_1	LAB	NA	HP_C7	planned		
junos1	LAB	NA	Junos	planned		
switch10	LAB	SV	Cisco_IOS	planned		
switch11	LAB	SV	Cisco_IOS	planned		
switch12	LAB	SV	Cisco_IOS	planned		
switch13	LAB	SV	Cisco_IOS	planned		

New

Edit

Delete

Ports

Topology

Vrf

Search

Client

The client area shows all the clients to which the user has permission. Each client listed shows the *Name*, the [Region](#), the number of [supernets](#), the status and the permission of the user to the client.

The Client is the top of the tree, which can contain multiple sites, which can contain multiple services, which can contain multiple nodes.

Deletion of a Client is only possible, when there are no more sites associated.

More details on the [Client](#)

Site

The site area shows all the sites of the selected client. The name of the site, the site-type, the address zip code and city (when known), the site status.

Deletion of a site is only possible when all the services on the site are deleted.

More details on the [Site](#)

Nodes / Services

This area lists all the nodes of the selected client. When a site on this client is selected, only the nodes of that site will be shown. The same applies for services.

A node is always linked to one service, while a service may be linked to multiple nodes.


More details on the [Nodes](#)

More details on the [Services](#)

Create a new node

In order to create a new node, you have to create a new service. You can do this with the button "Create services, below the nodes grid. This will open a window that allows you to select a service class to run.

Add node to site



DC_CORE

DCAggregate

2x AccessV

2x AccessU

Service	Class	Limi...	Use...
DC_CORE	DC_CORE	1	0
DCAggregate	DCAggregate	10	0
DC_ACCESS	DC_ACCESS	0	0

Cancel

Add node

The options you can select are based on the service classes you have defined for the site type of your site. More information of this can be found at the [Site types](#) section.

You can select both in the image and in the grid, and you can only select a service class that hasn't exceeded its limit of nodes within this site. When you have selected the service class you can click on the “Add node” button to go add your node.

Execute service task

Site:

EVE-ng

Client:

LAB

Service class:

LAB

Service type:

api

Service task:

✓ LocPort

newClientIpPlan

Start


Create log

Cancel

The next screen will allow you to select a specific service type, defined in the service types. More information of this can be found at the [Service-types](#) section.

When you click on the “start”-button, the service task “Create” of this service type will be run. It will do everything that you have specified in order, and will report its actions in the 'Create log' field at the bottom half of the form, including any errors that might have occurred. When finished, a button appears at the bottom that can take you to the form that corresponds to the service that has just been created.


Graph



The graph button will show the network based on the information in the database. This can be shown on Client level as well as on site level. Nodes can be positioned and saved within the view.

Connections overview

This picture will give you an idea on how this and the information of the subsections is tied together.



From:

<https://yce-wiki.netyce.com/> - **Technical documentation**

Permanent link:

<https://yce-wiki.netyce.com/doku.php/menu:inventory:main:main>Last update: **2022/04/28 15:54**